

Cont'd from Pg. 6

room corner, leaving an inch or more excess to permit scribing and/or accurate measuring to compensate for out-of-plumb corner. Keep panel edge exactly parallel with previously installed panel. (Slight irregularities will be concealed by corner molding).

Installation with nails. Paneling should be nailed to furring, studs, or sheathing with 1" brads or 3d (three-penny, 1 1/4") finishing nails, every 6" along panel edges and every 12" along intermediate furring. Toe-nail (at an angle) at joints through bevels and grooves. Conceal nail heads with matching Weldwood Blend Stik. Be careful not to dent or mark the panel face with hammer head. Use nailset.

Installation with Weldwood Panel Adhesive. This is the easy way. And it allows you time to adjust the panel into tightest fit before the panel is locked into place. Follow label directions carefully for a perfect bond.

Over a masonry wall or any damp wall

Masonry walls, especially when below ground level, pose only one serious problem . . . they're damp. The paneler must be certain that dampness released by concrete or brick or stone will not harm the panels.

First, cure any problems of dampness. (Your Weldwood Dealer can advise on commercial compounds available. Be sure the paneling you select is appropriate for the location you have in mind. Weldwood Prefinished Hardwood Paneling is least likely to be affected.

Second, include a vinyl plastic vapor barrier and insulation in your materials list and use according to manufacturer's instruction.

Third, build a suitable frame of 2 x 3 lumber over the entire wall, as we've shown. (Shim out as necessary). Fasten the frame directly to the wall with nails or screws into plugs or expansion shields, or fasten with hardened cut nails, bolt anchors, adhesive anchors or adhesive. Or (easiest of all) add spacers (1 x 2 furring) between the frame and the masonry wall and wedge and nail the frame tight against floor and ceiling.

Fourth, install paneling to frame just as you would over furring. Shim out frame from wall where necessary. Use same nailing schedule or adhesive method as with furring on a dry wall.

ranges and dryers will be manufactured with the cord and plug set attached.

Plug-in ranges and dryers are a boon to the homeowner as they provide convenience and safety. Appliances can be connected and disconnected quickly, without employing a serviceman and paying a service charge. This is a big advantage when cleaning or decorating the kitchen or basement.

When a family moves, the 240-volt appliances can be disconnected by the movers as quickly, easily and safely as a refrigerator or any other low-voltage unit. At the new location, they are just as easily reconnected without any delay or extra expense.

A vigorous Canada-wide

education program is being conducted by the Canadian Appliance Manufacturers Association to ensure that all Canadians are aware of this new development for consumer safety and convenience.

WATCH
FOR
OUR
OUTDOOR
supplement
ON
May 26

"The drycleaning store that offers you more"

**Amazing
Drycleaning
Discovery!**

★ WANT WHITER
WHITES?

★ BRIGHTER COLORS?

★ MORE VIVID
COLOR CONTRASTS?

★ NON-YELLOWING?

Every garment cleaned in our
plant is treated with new
exclusive

Adco's

**Adco-Lite
Charge**

"OPTICAL BRIGHTENER"

"When in Nipigon shopping, leave your cleaning with us,
it will be ready when you leave."

NIPIGON DRY-CLEANING

PH: 887-9973 - NIPIGON, ONT.

Every
Garment
Cleaned
by us
Receives

FREE

MOTHPROOFING

by the famous
MOTHINE process



PLUS

- ✓ SANITIZING
- ✓ DEODORIZING
- ✓ MOTHPROOFING
- ✓ MILDEWPROOFING

Cont'd from Pg. 7

stalled in a new home or apartment.

Heavy-duty cord sets fitted with molded-on plug for either range or dryer will be sold as a package through appliance dealers, hardware dealers,

electrical supply houses and electrical contractors. Simplified instructions for their installation will be included with the package.

After the new cord sets and receptacles are in general use for some time, all new electric